INSTRUCTION MANUAL

Read all the instruction carefully before you use the appliance and keep it for future use.



2000W BATHROOM HEATER



USER INSTRUCTIONS:

IMPORTANT: READ THESE INSTRUCTIONS FULLY BEFORE USING THE HEATER. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

NOTE: The frost protector with thermostat is for keeping small It is for use within the home or for similar purposes. The heater may only be used in a fixed position and only for the purpose described.

It is not for outdoor use!

SAFETY INSTRUCTIONS

- 01) This product is a wall mounting appliance, never use it as portable appliance.
- 02) Do not use the heater unless the feet are correctly attached if the heater is used as portable appliance.
- 03) This heater in designed for wall mounting and must be used with the warm air vent facing downwards. This heater should not be used in any other orientation and should not be used as a free standing portable appliance.
- 04) This heater must be installed so that switches and other controls (except the pull cord) cannot be touched by person in the bath or shower
- 05) This product is suitable for installation on surfaces with normal flammability e.g. wood, plasterboard, masonry. It is not suitable for use on highly flammable surface (e.g. polystyrene, textiles)
- 06) The heater is to be installed so that switches and other controls cannot be touched by a person in the bath or shower.
- 07) Before making fixing hole(s), check that there are no obstruction hidden beneath the mounting surface such as pipes or cables.
- 08) The chosen location of your new heater should allow for the product to be securely mounted(e.g. to a firm wall) and safely connected to mains supply
- 09) Ensure the power supply to the socket into which the heater is plugged is in accordance with the rating label on the heater and that the socket is earthed.
- 10) Keep the mains lead away from the hot body of the heater.
- 11) Do not use outdoors.
- 12) Do not cover or obstruct any of the heat outlet grilles or the air intake openings of the heater.
- 13) Do not place the heater on carpets having a very deep pile.
- 14) Always ensure that the heater is placed on a firm level surface. Ensure that the heater is not positioned close to curtains or furniture as this could create a fire hazard.
- 15) Do not position the heater in front of, or immediately below, a wall socket.
- 16) Do not insert any object through the heat outlet or air intake grilles of the heater.
- 17) Do not use the heater in areas where flammable liquids are stored or where flammable fumes may be present.
- 18) Particular care should be taken when the heater is situated in areas occupied by children or invalids.
- 19) Always unplug the heater when moving it from one location to another.
- 20) Do not use the heater if the power cord is damaged. If the power cord is damaged it must be replaced by a recognised service agent or other qualified person.

- 21) Only use a suitable 220-240V electrical socket.
- 22) The room which is to be heated should not contain any easy inflammable materials (e.g., petrol, solvents, spray cannisters etc.) or other easy combustible materials (e.g., wood or paper). Keep such materials away form equipment. Risk of fire!!
- 23) This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge,unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

OVERVIEW

1 gear indication

2 pull switch

OPERATION

0 stall: Shutdown

* stall : turbo


1 stall: 1000W

2 stall: 2000W



MOUNTING AND ELECTRICAL CONNECTION

- 1. According to the dimension of drawing A and B, drill three holes which the diameter is 8mm and deepness is 40mm in the wall.
- 2. According to the drawing C, put the three plastic expansion tube into the hole, drill the screw
 - into the parallel expansion tube, remain the distance from the head of screw to the wall 5mm. (see drawing D)
- According to the drawing E, hang the product on the screw.
- According to the drawing F, use the plastic plate to press on the product, then drill the screw into it to av




FIGURES FOR WALL MOUNTING

MOUNTING AREA

NOTE:

This product is suitable for mounting in Zone 3 or the safe zone of a bathroom (or similar) only if a permanent connection to the mains supply is made in accordance with the requirements of the building Regulations (including the wiring Regulations).

If in doubt, consult a qualified electrician.



OPERATION OF THE HEATER

NOTE: It is normal when the heaters are turned on for the first time or when they are turned on after having not been used for a long period of time the heaters may emit some smell and fumes. This will disappear when the heater has been on a short while.

CLEANING THE HEATER

- 1) Always un-plug the heater from the wall socket and allow it to cool down before cleaning.
- 2) Clean the outside of the heater by wiping with a damp cloth and buff with a dry cloth. Do not use any detergents or abrasives and do not allow any water to enter the heater.

STORING THE HEATER

When the heater is not used for long periods of time it should be protected from dust and stored in a clean dry place.

CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.









Code: 31416c



Elpine B20 3BT UK